

SOLO STOVE SUMMIT 24™
SMOKELESS FIRE PIT



Read full manual before using.

ENGLISH	1
ESPAÑOL	7
FRANÇAIS	13
DANSK	19
DEUTSCH	25
ITALIANO	31
NEDERLANDS	37
NORSK	43
PORTUGUÊS	49
SUOMI	55
SVENSKA	61


Solo Stove

SAFETY PRECAUTIONS


▲ WARNING! FOR OUTDOOR USE ONLY!

1. Do not use Solo Stove fire pits until you have read the operating instructions and user warnings. Serious injury, death, and/or property damage may occur.
2. Always use Solo Stove fire pits in accordance with all applicable local, state, and national codes. Contact your local fire department for details.
3. Solo Stove fire pits are not toys and can be dangerous. When using Solo Stove fire pits, exercise the same caution you would with an open fire.
4. Do not operate Solo Stove fire pits if under the age of 18 unless under strict adult supervision.
5. Never leave Solo Stove fire pits unattended while hot, especially when children or pets are nearby or when used on or near potentially combustible surfaces.
6. Do not alter or modify Solo Stove fire pits in any manner. Doing so could result in serious injury, death, and/or property damage.
7. Solo Stove fire pits are for outdoor use only.
8. Do not use Solo Stove fire pits for indoor heating. Toxic carbon monoxide can accumulate and cause asphyxiation and possibly death.
9. Do not use Solo Stove fire pits in a building, a garage, or any other enclosed area.
10. Do not use Solo Stove fire pits under any overhead or near any unprotected combustible construction. Avoid using near overhanging trees or shrubs.
11. Always use Solo Stove fire pits on a level, noncombustible surface.
12. NOTICE: Exercise extreme caution when using Solo Stove fire pits on or around combustible surfaces. Use on wood or composite decking is at your own risk and can lead to charring or ignition if not adequately elevated or insulated, or if misused.
13. Do not use gasoline, kerosene, or diesel fuel to light or relight Solo Stove fire pits.
14. Do not lean over Solo Stove fire pits when lighting or when they are in use.
15. Solo Stove fire pits are extremely hot when in use. Never touch or attempt to move your fire pit during use or before it has completely cooled down.
16. Do not lean against or let any body part touch Solo Stove fire pits during use or after use until they have completely cooled down.
17. Do not lean any objects against Solo Stove fire pits while in use.
18. Do not store or use gasoline or any other flammable vapors or liquids in the vicinity of Solo Stove fire pits while in use.
19. Do not use Solo Stove fire pits on or near automobiles, trucks, vans, or recreational vehicles.
20. Keep all electrical cords away from Solo Stove fire pits.
21. Do not use Solo Stove fire pits in windy conditions.
22. Do not wear flammable or loose clothing when operating Solo Stove fire pits.
23. The use of alcohol, prescription drugs, or non-prescription drugs may impair the consumer's ability to operate Solo Stove fire pits safely.
24. Solo Stove fire pits are designed for use with standard firewood logs and may not function properly with other fuel sources.
25. Do not use water to extinguish the fire as this could cause damage to the fire pit as well as injury to the user.
26. Dispose of ashes properly! Ashes should be placed into a metal container with a sealed metal lid.
27. After a period of nonuse, check your Solo Stove fire pit for signs of damage and creosote buildup.
28. Solo Stove fire pits are not for commercial use.
29. Any use of Solo Stove Fire Starter Gel™ or Starters must comply with the lighting instructions on page 5 of this manual.

COMPONENTS



RECOMMENDED FUEL



SOLO STOVE SUMMIT 24™

SMOKELESS FIRE PIT FEATURES

Built-In Stand

Ensures you can safely enjoy your fire on most surfaces like grass, turf, patios, or wood decking. No assembly required.

Quick-Strike Cone™

A patented, intuitive fire pit solution that makes lighting a fire easier than ever. Compatible with Solo Stove Fire Starter Gel™ or Starters.

Optimized Wall Height

We've engineered a lower Fire Pit wall to show more flame without sacrificing our unrivaled smokeless experience.

Unrivaled Smokeless Tech

Solo Stove's Signature 360° Airflow™ and Secondary Burn create a cleaner, low-smoke burn for a better fireside experience—improved in Summit 24™ with even better airflow performance.

Premium Stainless Steel




Built with premium stainless steel for a durable, corrosion-resistant experience and years circled up around the pit.

Lifetime Warranty

Comes with a lifetime warranty, so you can enjoy your Fire Pit for years to come.

Removable Ash Pan

Rests beneath the base plate, catching all the ash in one place. Just lift, empty, and boom—you're ready for your next fire.



TIPS FOR OPTIMAL PERFORMANCE

1. Start your fire with fuel or fire starters.

The Quick-Strike Cone™ makes lighting the fire really easy and takes away the guesswork. Make sure to use Solo Stove Fire Starter Gel™ or Starters for best performance.

2. Let the fire build strong embers before adding more wood.

Give the fire a few minutes to build a strong ember bed and get hotter, which will activate the Secondary Burn and smokeless experience.

3. Use dry, split hardwood only.

Wet or soft wood will produce smoke and reduce burn efficiency.

4. Do not overfill the fire pit above the vent holes.

Keep logs below the top vent holes to allow for full airflow and smoke-free performance.



5. Allow walls to heat up to improve smokeless airflow.

For the ultimate smokeless burn, allow the wood and fire to expand to the edge of the fire pit. Heating up the base of the wall will optimize the smokeless technology airflow.

HOW TO ASSEMBLE YOUR FIRE PIT

1. Unbox Your Fire Pit



Remove the Fire Pit and all internal components: Flame Ring, Ash Pan, and Quick-Strike Cone™.



2. Install the Ash Pan and Quick-Strike Cone™


A) Place the Ash Pan in the center of the Fire Pit.

B) Set the Quick-Strike Cone™ (dome-side up) on top of it.



3. Insert the Flame Ring


Position the Flame Ring with the dome shape and flame logo facing upward to optimize airflow and flame protection.



HOW TO IGNITE: OPTION 1, SOLO STOVE FIRE STARTER GEL™

1. Place Your Firewood


Stack small dry split wood horizontally around the Cone. Start with less wood, about 5-6 split logs.



2. Igniting with

Solo Stove Fire Starter Gel™


Pour one full packet of gel fuel onto the Cone until it collects in the pool indents at the base of the fire pit.



Use a longneck lighter to quickly (within 1 minute of pouring) ignite the gel on top of the Cone. The flame will ignite the pooled gel beneath kindling. If wood doesn't light, wait to repeat the process. DO NOT pour more gel until the pit is completely cool.

3. Tend the Fire

Add wood gradually over time to keep the fire going. Avoid over-stuffing the chamber or stacking above the vent holes, as this will block airflow and create smoke.



4. Let It Burn Out Naturally

Don't pour water on the fire. Let it extinguish and cool on its own before cleaning the fire pit.

▲ WARNING



SURFACES WILL BE EXTREMELY HOT DURING AND AFTER USE.
HANDLE WITH CARE.

HOW TO IGNITE: OPTION 2, SOLO STOVE STARTERS

1. Place the Starters


If using Solo Stove Starters, place them in the pool indents around the Quick-Strike Cone™ before you add your firewood.

With a lighter, light the Starters.
They should take about 5-15 seconds to catch fire.




2. Place Your Firewood

Stack small dry split wood horizontally around the Cone. Start with less wood, about 5-6 split logs.



3. Tend the Fire

Add wood gradually over time to keep the fire going. Avoid over-stuffing the chamber or stacking above the vent holes, as this will block airflow and create smoke.



4. Let It Burn Out Naturally

Don't pour water on the fire. Let it extinguish and cool on its own before cleaning the fire pit.

▲ WARNING

SURFACES WILL BE EXTREMELY HOT DURING AND AFTER USE.
HANDLE WITH CARE.

CLEANING AND STORAGE

- Check for creosote buildup regularly. Periodically check for wear or black, tar-like buildup from previous burns—it's a natural byproduct of wood fires called creosote.
- Allow the Fire Pit to fully cool before cleaning.
- Remove the Quick-Strike Cone™, then the Ash Pan. Empty cooled ashes into a metal container with a sealable lid.
- Clean the body of the Fire Pit with mild soap and warm water using a soft cloth.
- Use the Solo Stove Shelter (sold separately) when storing outdoors.

RESTORE SHINE

1. Let the Fire Pit warm slightly or sit in the sun to loosen the surface buildup.
2. After it fully cools down, clean it with a soft cloth and stainless-steel polish.
3. Buff it to restore a consistent, brushed-metal finish.
4. Do not use steel wool or harsh abrasives on the surface.

TROUBLESHOOTING

For assistance, visit solostove.com or contact Solo Customer Support at **817-900-2663** 9AM - 7PM, CT, Monday - Friday

For more information, you can also visit solostove.com

SOLO BRANDS, LLC
1001 Mustang Dr.
Grapevine, TX 76051
solostove.com

V. SS24_SD_3.0_090425

WARRANTY

You're eligible for our lifetime warranty.

See full details at solostove.com or by scanning this QR code:

