CANOPY RO1

Single Standard | Single system

220-240V

Available for

A-Tube Nano Series | Kelly Cluster | Nostalgia Series | Rain | Random | Spider

Ita-Eng

2017.03.06

2

Disinserire la tensione prima di operare sull'apparecchio

ISTRUZIONI DI MONTAGGIO

1) Aprire la scatola a soffitto [A] svitando il grano [E] e rimuovere il disco [C] (vedi Fig.1 e Fig.2)
2) Fissare al soffitto la scatola [A] attraverso le asole [G] predisposte
3) Dopo aver letto le istruzioni della sospensione scelta inserire il cavo elettrico come di seguito indicato.
4) Inserire prima il cavo [S] nel foro del disco copriscatola [C] e successivamente al centro della staffa [F]
5) Passare poi il cavo [S] all'interno del bloccacavo a ponte [D]
6) Agire sul bloccacavo [D] (vedi Fig.3) per regolare l'altezza della lampada.
7) Stringere quindi accuratamente il bloccacavo [D] per bloccare il cavo.
8) Collegare la linea principale con i cavi della sospensione [S] ai morsetti [B] (vedi Fig.4)
9) Richiudere la scatola a soffitto [A] con il disco copriscatola [C] bloccandolo con il grano [E] (Fig.2)

Before installing turn off the power to the electrical box

MOUNTING INSTRUCTIONS

1) Undo the grub screw [E] and separate the lid from the ceiling plate [A] (Fig.1 and see Fig.2)
2) Fix the ceiling plate [A] to the ceiling using appropriate fixings [G]
3) After reading the instructions for chosen suspension insert the power cable as follows.
4) Insert the cable [S] through the hole of the lid [C] and through the hole of the omega bracket [F] of the ceiling plate.
5) Then insert the power cable [S] inside the cable grip [D]
6) To adjust the length of the power cable undo the screws on the cable grip [D] and slide the cable through the grip to obtain the requested length (Fig.3)
7) Thighten carefully the screws to block the cable in the cable grip [D]
8) Connect the power supply and the suspension wires [S] with the terminal blocks [B] (see Fig.4)
9) Slide the lid [C] over the ceiling plate [A] and secure it in position using the set screw [E] (Fig.2)

Fig.1





Fig.3

Fig.4

Fig.2

Studio Italia Design garantisce i suoi prodotti essere privi da difetti di materiale e di lavorazione per la durata di un anno dalla consegna. Durantetale periodo Studio Italia Design riparerà o sostituirà, a sua discrezione,i prodotti che hanno dato prova di difetto. Questa garanzia non è applicata a danni risultanti dall'incidente, alterazione, manomissione, abuso o negligenza. Ogni modifica può compromettere la sicurezza rendendo l'apparecchio pericoloso. Studio Italia Design declina ogni responsabilità per i prodotti modificati. L'apparecchio non deve essere installato in posizioni o in applicazioni diverse da quelle indicate nelle istruzioni di montaggio.

Studio Italia Design warrants its to be free from defects in materials and workmanship for a period of one year date of delivery. During this warranty period Studio Italia Design will repair or replace, at its option, product that are proven to be defective. This warranty does not apply to damages resulting from accidental, alteration, tampering, misuse, negligence or abuse. Any modification may compromise safety causing the product to become dangerous. Studio Italia Design declines all responsability for products that are modified. Fixture must not be installed in any position or used in a different way than shown in his instructions.

Conservare le istruzioni per una manutenzione futura. L'apparecchio deve essere installato da personale qualificato
Keep these instructions for future reference. To be installed by a qualified licensed electrician only

CE

STUDIO ITALIA DESIGN | Via Pialoi, 32, 30020, Marcon, Venezia, ITALY | www.studioitaliadesign.com | info@studioitaliadesign.com

STUDIO ITALIA DESIGN